

General:

(A) Install over solid sheathing with housewrap underlay. You may install furring strips over that for uneven surfaces, or to allow insulation between furring strips, but that does not alleviate the need for sheathing/housewrap.

(B) Fasten panels with pancake or hex head screw 2' on center.

